



232 North Branford RD.
North Branford, CT 06471
Orders: 203.481.9460
Tech: 203.481.9943
Fax: 203.481.9641

Installation Instructions

#77-272 - Mini Cooper Gen 1 Power Steering Tank

NOTE: We recommend removing the coolant tank to ease installation.

1. Drain the fluid from both the coolant tank and the power steering tank.
2. Unbolt the coolant tank and remove the hose on top of the tank.

3. Once the tank is unbolted and the top hose is removed you will have the ability to pull the tank up and get to the bottom hose to remove it.

4. After the coolant tank is removed you will need to unbolt the power steering tank and remove both hoses on the bottom of the tank.



NOTE: The rubber grommets from the stock tank must be used. To remove you will first need to remove the metal sleeve inside.

NOTE: We recommend replacing the hose clamps while replacing the tank in order to prevent any leaks.



5. Install the power steering tank by attaching the hoses first.
6. Be sure to feed the coolant line through the power steering bracket before bolting the power steering tank in.
7. Reinstall the coolant tank by attaching the hoses first.
8. Refill fluids and put the caps on and you are finished.



**VISIT OUR YOUTUBE PAGE TO SEE OUR
FULL INSTALLATION VIDEO.
WWW.YOUTUBE.COM/CANTONRACING**

www.CantonRacingProducts.com