



FORD 302/351W BILLET WATER NECKS #80-026, 80-036, 80-056

INSTALLATION NOTICE:

These water necks were designed to work with most aftermarket thermostats.

We recommend one of the following:

Stant #13009
Stant #45359
Gates #33009S
AC Delco #13267

They **WILL NOT** fit the OEM Motorcraft #RT1139.



STANT 13009

STANT 45359

GATES 33009S

AC DELCO 13267

~~NO!!! RT1139~~

