

232 Branford Rd. North Branford, CT 06471

Orders: 203.481.9460

Tech: 203.481.9943


Fax: 203.481.9641

## Product Instructions

Part # 22-545, 22-546, 22-547, 22-548 and 22-549

Spin-on to engine side

Cooler Feed Port oil from engine passes through adapter to the cooler



Cooler Return Port

oil from cooler
passes through adapter
and on to filter

Filtered oil back to engine

**Install filter Side** 

Cooler Feed Port (line to Cooler)
Cooler Return Port (line from Cooler)

1. Remove Adapter contents and confirm quantities.

- a) (1) Oil Adapter
- b) (1) Adapter nut
- c) (1) O-ring installed on Adapter



- 2. Take adapter assembly and apply a small amount of oil to the O-ring surface and install adapter assembly with O-ring facing towards the engine block (As Shown Below).
- 3. Hold adapter with ports facing desired direction and tighten center nut onto your blocks filter nipple by hand then using a 1-1/4" wrench.



www.CantonRacingProducts.com