




232 Branford Rd.
North Branford, CT 06471
Orders: 203-481-9460
Tech: 203-481-9943
Fax: 203-481-9641

Fuel Filter Installation Instructions

25-918 CM -15 Fuel Filter - Recirculating 1/4" NPT "Y" Block Filter

This filter allows for plumbing of a return or bypass style fuel system without requiring a fuel line to be run back to the fuel tank. Install this filter between your fuel tank and fuel pump. On the dual port side of the filter plumb one of the ports to your fuel pump. The other port will serve as your return line. This set up does not require a return line to the tank.

NOTE: See Diagram Below For Plumbing.



**NOTE: Either port can be plumbed
as the outlet or return**